

SEG Installation Instructions

- 1** Insert 8" to 10" of cover with SEG gasket into corner grooves of the frame.



- 2** Insert middles of each side into the groove and continue in an outward direction.



- 3** If SEG needs adjusting:
- If there is bunching it can be worked in by pushing/pulling the gasket towards the corners.
 - If the gasket seems to long:
 - 1st, make sure gasket is completely flush in opposite corner
 - 2nd, it can be worked in by pushing/pulling the gasket towards the opposite end.

