



ECONOMY RETRACTABLE


INSTRUCTION SHEET




- 1** Remove unit from bag and turn stabilizing feet to a 90° angle.



- 2** Assemble three piece bungee pole(s).




- 3** Secure pole in the base of stand.




- 4** Gently lean the unit back and pull the graphic up by the top rail and connect hook into the top of the pole.




How to attach or replace graphics.




- 1** Pull graphic out until the leader is exposed. Insert locking pin to disable the roller.*




- 2** Remove graphic and replace.




- 3** Remove end caps and pull open the snap lock profile.



- 4** Once the snap-lock Profile is open insert top portion of graphic into profile.*



- 5** Apply even pressure to the snap-lock profile to lock graphic into place. Replace end caps.



- 6** Grip image and unit securely and remove locking pin. Slowly guide image back into unit.

*** CAUTION:** Do not remove the locking pin until the profile is attached to the graphic and the graphic is attached to the leader.